

NEW FRESH SCENT

FAST & EFFECTIVE A READY TO USE DISINFECTANT

CLEANER WIPE



RX 75 ANTIBACTERIAL H.D. DISINFECTANT CLEANER WIPES

Other quaternary disinfectants have failed EPA requirements against *M. Tuberculosis* because the *TB bacillus* is covered by a tough protective shell that the typical quat cannot pierce. The superior penetration of RX 75 allows it to quickly break through this shell and to kill the disease-causing bacilli, just as it kills a broad range of other Gram negative and Gram positive bacteria,

and as it kills *HIV1* (the AIDS virus) and pathogenic fungi. But RX 75 Wipes are not just to guard against cross infection.....the ability to penetrate the shell of the *TB bacillus* is indicative of its ability to penetrate and remove the worst stubborn soil. You'll find RX 75 to be the best cleaning "wipe" product you have ever used. They are ready to use right out of the handy tubs.



Penetrates the tough shell of the TB bacillus.



ACTERIAL HEAVY D

Kills Norwalk Virus, MRSA. VRE and HIV-1.



Suitable for clean-up of blood and OPIMs.



Premoistened & ready to use anti-bacterial cleaner.

RX 75 ANTIBACTERIAL H.D. CLEANER WIPES

DISINFECTION

Efficacy tests have demonstrated that this product is an effective bactericide, fungicide and virucide in the presence of organic soil (5% blood serum). When used as directed and detailed on the label, RX 75 exhibits effective disinfectant activity against Mycobacterium tuberculosis (BCG), Norwalk virus, Pseudomonas aeruginosa, Staphylococcus aureus, Salmonella choleraesuis. Methicillin Staphylococcus aureus (MRSA), Vancomycin resistant Enterococcus faecalis (VRE), Vancomycin intermediate resistant Staphylococcus aureus (VISA), HIV-1 (associated with AIDS), Hepatitis A Virus (HAV), and Feline Calicivirus and meets the requirements for hospital use.

DESCRIPTION

RX 75 ANTIBACTERIAL HEAVY DUTY DISINFECTANT CLEANER WIPES are a ready to use quaternary ammonium based disinfectant cleaner that is unique in its ability to kill the M. Tuberculosis bacillus in addition to a broad range of other Gram positive and Gram negative bacteria, as well as the AIDS virus and pathogenic fungi. As a wipe cleaner the same superior penetrating ability that allows RX 75 to pierce the tough waxy shell surrounding the TB organism makes it outstanding in its ability to penetrate, loosen and remove stubborn, heavy soil.

Packaged in convenient 6 each 120mm canisters with 180 6"x 8" towels that are ready to use right out of the package. Makes it easy to clean and disinfect anywhere, anytime.

SPECIFICATIONS

	ACTIVE INGREDIENTS	
n-Alkyl (60% C ₁₄ , 30% C ₁₆ , 5% C ₁₂ , 5% C ₁₈		₂ , 5% C ₁₈
		lorides0.105%
	n-Alkyl (68% C ₁₂ , 32% C ₁₄) diethy	
	ethylbenzyl ammonium chlorid	es0.105%
INERT INGREDIENTS		
	Includes cleaners and odor cour	nteractant <u>99.790%</u>
	TOTAL	100.000%
	TYPE GERMICIDES	Dual quaternary blend
	TYPE DETERGENTS	non-ionic
	ODOR COUNTERACTANT	
	COLOR	
	pH	12.5 ± 0.5
	VISCOSITY	Water thin
	PHOSPHATE CONTENT	
	FREEZE-THAW STABILITY	
	BIODEGRADABILITY	
		detergents & germicides
	SHELF LIFE	2 years minimum
	SPECIFIC GRAVITY	1.01 + .01
	FLASH POINT	None to boiling point
	EPA REGISTRATION NO	1839-174-44089

BENEFITS

KILLS M. TUBERCULOSIS BACILLUS because it can penetrate the tough waxy shell that surrounds the bacteria that resists typical quaternary disinfectants.

KILLS HIV 1 VIRUS associated with AIDS.

HOSPITAL TYPE: Kills a broad range of Gram negative and Gram positive bacteria including Pseudomonas aeruginosa.

A SUPERIOR CLEANER/DEGREASER: Penetrates, liquifies and removes oily, greasy soil.

ODOR COUNTERACTANT: Contains AIRICIDE® and a pleasant lemon fragrance to eliminate foul odors in the air and kill putrefactive bacteria that produce such odors.

NON-FLAMMABLE: Contains no alcohol or other flammable components.

BIODEGRADABLE: Both the surfactant and the disinfectant are biodegradable - contains no phosphates.

ECONOMICAL: 180 - 6" x 8" Disinfectant wipes per canister.

PLEASANT AROMA: Contains no phenol, so there's no unpleasant phenolic odor during or after use.

CONVENIENT: RX 75 comes ready to use. There's nothing to mix at the time of need. Just pull out a wipe and the contaminated surface can be disinfectant clean.

USES

For disinfecting and cleaning hard, non-porous inanimate environmental surfaces in hospitals, nursing homes, patient rooms, operating rooms, public restrooms, schools, food service establishments, transportation terminals, office buildings, manufacturing facilities, lodging establishments, veterinary clinics, athletic & recreational facilities.

DIRECTIONS FOR USE

Use one RX 75 ANTIBACTERIAL HEAVY DUTY DISINFECTANT CLEANER WIPE to remove gross filth and heavy soil. Using another wipe, allow treated surface to remain wet for ten minutes, then wipe off with clean cloth or sponge. Treated surface must be visibly wet for disinfection. A potable water rinse is required for surfaces in direct contact with food.

DISTRIBUTED BY:



3 Chattanooga Irvine, CA 92620-2514

Tel 714-832-8441

info@chemexindustries.com industries, inc. www.chemexindustries.com