



# APPLICATION GUIDE HIGH PERFORMANCE FLOORS

## Step 1 – Preparation

- **Data Sheets** - Read the Technical & Safety Data Sheet for all products being used. Follow steps below along with any safety, preparation, and application instructions listed on the product's data sheets.
- **Test Patch** - Prior to full application, apply a test patch to ensure the system chosen is appropriate for the project. If results do not meet expectations, contact Monopole Inc. for recommendations.
- **Surface Condition** - All surfaces must be fully cured, firm, and dry. Concrete, stucco, and masonry must be cured for 30 days. Remove all loose, peeling, and poorly bonded paint.
- **Moisture** - Wood must have < 13% moisture content. Concrete, stucco, and masonry must have < 15% moisture content. Do not apply coatings to surfaces with hydrostatic pressure.
- **Environment** - Material, air, and surface temperature must be between 40°F - 90°F and 5° above the dew point. Do not expose to moisture during application and dry time. Limit heavy moisture 24-48 hours after application.
- **Surface Profile** - Mechanically grind smooth, glossy, dense, or glazed surfaces to create a rough profile similar to 120-180 grit sandpaper.
- **Cleaning** - Use an appropriate cleaning method and/or solution to ensure all surfaces are free of dust, dirt, oil, grease, wax, chalk, rust, mildew or any other contamination or condition.
- **Patching** - Fill and seal any voids, seams, or cracks using a paintable patching material and allow to fully cure.

## Step 2 – Primer

- **1 Coat** - Monochem 21 Epoxy Primer @ 10-12 Wet Mils
- **Pot Life** - 15-20 Minutes - *Once mixed, immediately pour all material onto the surface - Apply within 20 minutes*
- **Additives (Optional)** - While primer is wet, broadcast texture aggregate, quartz granules, or color chips
- **Dry Time** - 3-6 Hours Topcoat - *Do not exceed 12 hours*

## Step 3 – Topcoat

- **2 Coats** - Permashield 2K Polyaspartic (2000) @ 14-16 Wet Mils - *Do not apply at less than 5 wet mils. Do not wait longer than 12 hours between coats.*
- **Additives (Optional)** - Mix texture or metallic additives into Part A of First Coat before activating with Part B - Second Coat should be applied additive free

	1400 Standard Fast-Cure	1500 Extended Time
<b>Pot Life</b>	15-20 Mins	45-60 Minutes
<b>Dry Time</b>	2-4 Hours – Recoat 6-8 Hours - Light Foot Traffic 12-24 Hours - Full Use	2-4 Hours - Recoat 4-6 Hours - Light Foot Traffic 24-48 Hours - Full Use

## After Application

- **Drying** - Dry times are based on standard conditions of 75°F with a relative humidity of 50%. Lower temperatures or higher humidity may extend drying times. Higher temperatures may speed drying time. Provide adequate ventilation and air movement during and after application.
- **Cleaning** - Wait until at least two weeks after final application before cleaning the surface. Clean with fresh water and a cotton cloth. A small amount of mild detergent can be used, if necessary.

